

Ford Track Bar Installation

To ensure a secure fit follow the steps below

- Using a 27mm socket/wrench; Mount the track bar-to-axle. Torque to **(184ft/lbs)**
- Now with a 30mm socket/wrnehch; attach trackbar to frame. Torque to **(406ft/lbs)**
- With the truck on the ground adjust sleeve accordingly to center the axle under the frame. (41mm/46mm open end)

Professional alignment is recommended

(All ball joints are pre-greased. DO NOT add grease on install)



- **Adjustment sleeve Jam nut torque - 185lb/ft**

 **FOLLOW US**
@kryptoniteproducts

KRYPTONITEPRODUCTS.COM