INSTALL INSTRUCTIONS FOR 75-5062




BEFORE YOU START

- Please read the entire product guide before proceeding.
- Ensure all parts are present.
- If you are missing any of the components, call our customer support at (909) 947-0015.
- Do not work on your vehicle while the engine is hot.
- Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.
- Note: This intake kit may not fit with the following Aftermarket Parts installed: Body Lift or Lowering Kit, Custom Hood, Throttle Body Spacer / Upgrade


REQUIRED TOOLS

- 13mm Wrench/Socket
- 5/16", 15/32", & 1/2" Wrench & Socket
- 3/16" & #5 Metric Hex Key
- 5/16" Nut Driver or Flat Blade Screwdriver
- Drill and 3/4" Drill Bit (Optional)





BATTERY HOLD DOWN BLOCK DETAIL



BATTERY TRAY DETAIL

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	AG1018-00	Hose Clamp, #64	2
2	AI1059-00	Clip Nut, 1/4"-20	2
3	AI1073-00	Washer, 1/4", 5/16" ID, 47/64" OD, Zn Pltd	2
4	AI1080-00	Washer, Flat, 11/32" ID, 1-1/4" OD, .047 Thk, Zn Pltd	12
5	AI1090-00	Nut. NyLock, M6 (Battery Hold Down)	1
6	AI1131-00	Screw, Hex Head, 1/4-20 x 1.00, Gr 5, Zinc Pltd	2
7	AI1163-00	Bolt, Hex, 5/16"-18 x 1.00"	4
8	AI1330-00	Grommet	1
9	AI1333C-00	Coupler, Hump, 4.10 ID x 2.50 Long, Silicone	1
10	AI1410-00	5/16-18 Hex Bolt 1" Long	4
11	AI1413-00	HHCS, M6 x 1.0 x 93mm Long	1
12	AI1535-00	Washer, Flat, M6, 18 mm OD, DIN 9021, Zn Pltd	2
13	AI1586C-00	Fender Seal	1
14	AI1655-01	Clear Lid	1
15	AI1657C-00	Tube Seal	1
16	AI1683-00	18-8 SS Nylock Hex Nut, 5/16"-18 Thread	4
17	AI1687-00	Zinc-Plated, Hex Nut, M6x1.0, 10mm Wide, 5mm High	1
18	AI1814-00	Grommet	1
19	AI1816-00	Battery Block (Battery Hold Down)	1
20	AI1991-00	Washer, Oversized, 0.281" ID (Battery Hold Down)	3
21	AI2530C-00	Snap-In Seal	1
22	AL1198-00	Intake Tube	1
23	AL1198B-00	Air Box	1
24	AL1198S-00	Snorkel	1
25	AL1198T-00	Battery Tray	1
26	KF-1059	Air Filter	1

With the ignition switched off and the parking brake set, disconnect the negative battery cables on both batteries, then disconnect the positive battery cable on the driver's side only.

IMPORTANT: Failure to disconnect the battery for a minimum of 2 hours may cause the Check Engine Light to illuminate upon completion of the installation or subsequent operation. DO NOT SKIP THIS STEP!



STEP 2

Remove the stock battery cover by pressing down on the tabs in front of the battery.



Remove the battery bolt and wedge then remove the battery from the vehicle.



STEP 4

IF EQUIPPED: Disconnect the stock electronic restriction gauge electrical connector then read Step #16 and plan accordingly.



STEP 5

Loosen the hose clamp at the turbo inlet.



Unfasten and remove the stock airbox lid and intake tube assembly from the vehicle.



STEP 7

Remove the four bolts from the stock battery tray from the bottom and side.

NOTE: Early 99' models have a separate bracket with an additional bolt. Remove this bolt as well, then remove the tray from the vehicle.






STEP 7 (IMAGE 2)

From the inside of the stock airbox, turn the air temperature sensor a 1/4 turn to release it from the airbox.

Caution: Be careful not to damage the sensor.




STEP 9

Remove the airbox and tray from the vehicle.


NOTE: Early 99' model stock air boxes have 2 bolts at the inner fender that need to be removed prior to the removal of the airbox.





STEP 9 (IMAGE 2)

Install the Clip Nuts onto the Snorkel then slide the snorkel into the Airbox.



STEP 11

Secure the Snorkel with the 1/4"-20 Bolts and Washers. **Do not over tighten.**



STEP 12

Secure the Battery Tray to the Snorkel and Airbox with the 5/16"-18 Bolts, Washers and Lock Nuts. **Do not over tighten.**



Install the Grommet into the side of the Airbox.



STEP 14

Install the Fender Seal onto the Airbox.



STEP 15

Install the Tube Seal onto the Airbox.



READ BEFORE NEXT STEP

Note: The stock Restriction Gauge is not calibrated for the S&B Intake Kit, both types (Manual and Electronic) will no longer be accurate. However, the electronic type must be reconnected or the indicator light may be triggered.

Important: Service air filter according to S&B precision cleaning instructions. Do not rely on the restriction gauge or wait until the dash light is triggered.

IF EQUIPPED: To reinstall the electronic restriction gauge drill a 3/4" hole in the Intake Tube at the drill point and insert the Grommet .



STEP 16 (IMAGE 2)

STEP 17

Install the Intake Tube through the Tube Seal from inside the Airbox. Pull out the intake tube until it reaches the stop bead.




Install both #64 Hose Clamps onto the Coupler. Do not tighten yet.

STEP 19

Slide the coupler with both hose clamps onto and over the intake tube. Push the coupler past both stop beads leaving the end of the tube exposed.



Install the battery hardware to the Battery Tray. M6 Bolt, Split Washer, Washers and Jam Nut . Tighten the Jam Nut and M6 Bolt. Lock, do not install the battery block yet.



STEP 20 (IMAGE 2)

Install the complete airbox assembly into the vehicle.

STEP 22

Align the mounting holes for the Battery Tray going to the fender and underneath the airbox. Install the provided M8 Bolts and Washers through the battery tray which should thread into the factory clip nuts.

STEP 23

Install the provided M8 Bolts and Washers to secure the

Battery Tray to the fender.

STEP 24

Align the Intake Tube with the turbo inlet then slide the Coupler onto the turbo inlet.

STEP 25

Tighten the #64 Hose Clamp.

Install the Air Filter onto the Intake Tube and tighten the hose clamp. Make sure the filter flange is properly aligned with the stop bead before tightening completely. The filter and tube may need to be adjusted to fit straight with the box.

STEP 27

install the battery onto the battery tray.

Install the Battery Block over the M6 Bolt, then secure the block with a Washer and Lock Nut.

STOP! READ THIS BEFORE CONTINUING THE INSTALL

If your kit came with our new snap-in lid design, please proceed to **STEP 32** to install your snap-in lid. If your lid is the traditional screw in lid, please proceed to the next step.

STEP 29

Remove the protective covering from the Clear Lid.

Install the Edge Trim around the edge of the Clear Lid.

STEP 31

Secure the Clear Lid onto the AirBox with the 1/4"- 20 Screws and Washers.

Go To Step 35

For Snap-In Lids Only

Remove the protective covering from the Clear Lid.

STEP 33

For Snap-In Lids Only

Stretch silicone lid seal around the perimeter of the clear lid. It should be a snug fit.

STEP 34

For Snap-In Lids Only

The notch on the lid and the tab of the lid seal should

mate in the same corner.

STEP 35

Install the air temperature sensor into Airbox by pushing firmly into the grommet.

STEP 36

IF EQUIPPED: Reconnect the electronic restriction gauge and push it into the grommet on the intake tube. Press firmly to ensure a airtight seal.

Reconnect the negative terminal on the battery. Inspect your installation, make sure the kit is properly positioned and all fasteners are secure. Keep all stock parts in case you ever need to reinstall the stock intake assembly. Affix the ID label near the intake kit. The installation is now complete.

POWER STEERING RESERVOIR ACCESS

Turn the cap left to open the power steering reservoir. Lift up the cap until you can see the slanted portion for level indicator then slide the cap to the edge of the reservoir, slightly tip the cap and pull it out. It will take some force to get the cap out.

STEP 1 (IMAGE 2)

Use a paper or plastic funnel to refill your power steering fluid if needed. Reinstall the power steering reservoir cap.



WIN A FREE TOOL TRAY

Sign-up below to receive the latest on product launches, insider tips and more. You'll also be entered into a tool tray giveaway where we choose a new winner every week.

Email Address

Sign Up